

Residual Stress Analysis by X-Ray Diffraction

- or-

Those Propeller Stresses Had Better Be Compressive !!!

TEC / Materials Testing Division, Knoxville, TN USA



Acknowledgements

- T. Yentzer, Metallurgist, WR-ALC, Robins Air Force Base, GA
- B. Stillman, Aerospace Engineer, WR-ALC, Robins Air Force Base, GA
- M. Fisher, Aerospace Engineer, Litton/TASC, Warner Robins, GA
- T. Khaled, Chief Metallic Materials Advisor, FAA, Lakewood, CA




Outline

- Propeller blades and stresses.
- II. Why do we need compressive stresses?
- III. How do we put compressive stresses in propellers?
- IV. How can we tell what the stresses are?
- V. Results from the real world
- VI.Conclusions



Propeller Blades and Stresses

Blade retention feature





Why Do We Need Compressive Stresses?

- Propeller assembly is a highly energetic rotating assembly
- Blades operate under severe load conditions
- Dominant bending loads are imposed at the inboard retention feature
- Airplanes and helicopters are merely fatigue machines that operate above ground (hopefully!)
- Compressive stresses extend fatigue life



How Do We Put Compressive Stresses in Propellers?

- Plastically deform (move material in) the critical stress areas of a propeller
- Common methods of imparting compressive stresses:
 - Shot peening
 - Compression rolling
- Both methods put a compressive stress at the surface and a more compressive stress beneath the surface



How Can We Tell What the Stresses Are?

- Strain gage blind hole drilling
- X-ray diffraction



X-Ray Diffraction Residual Stress Measurement

Definition - A technique that combines physics, mechanics and alchemy to help one determine the useful life of a part.



Loading Versus Residual Stress

- Loading Stress results from applied load: weight, torsion, bending, pressure, pushing, pulling etc.
- Residual Stresses stresses that remain in the material after all external loads are removed. They result from differential cooling rates (Welding, Heat Treating, etc.) and plastic flow (Shot Peening, Cold Working, etc.).



Origin of Residual Stress

 Introduction by mechanical, thermal, and/or chemical processes that result in a permanent, nonuniform change in shape or volume.




Mechanical Processes

- Surface Working
 - Shot Peening
 - Surface Rolling
 - Polishing
- Drawing
- Rolling
- Grinding and Machining
- Assembling




Shot Peening





Forming





Benefits of X-Ray Diffraction Residual Stress Analysis

- Can be nondestructive
- Accurate stress vs. depth with electropolishing
- Repeatable
- Fast



Benefits (continued)

- Understand and quantify grinding burn to prevent component failure
- Analyze residual stresses vs. fatigue to aid in useful life estimation
- Find cause of warping in machined components
- Analyze heat affected zones of weldments to determine need for stress relief



Why Residual Stresses Are Important

- Residual stresses may be harmful or beneficial
- Tensile residual stresses at surface are normally harmful, sometimes leading to brittle fracture in fatigue
- Compressive residual stresses at surface normally increase fatigue strength
- Residual stresses can be controlled in the manufacturing process



INSERT History of Residual Stress (X-Ray Diffraction - XRD)



X-Ray Diffraction Stress Measurements

- Measures elastic strains
- Direct, self calibrating technique
- Measures long range stresses at a point
- Can measure complex geometries
- Can measure phase-by-phase stresses



X-Ray Diffraction Residual Stress Measurements

- If component is loaded, resultant stress will be the residual plus the applied stress
- Measurements can be made on most metals and ceramics; samples must be polycrystalline with relatively randomly oriented medium to fine grains
- Measurements can be made in a few minutes to an hour



X-Ray Diffraction Residual Stress Measurements

- Nondestructive* surface measurement techniques
- Measures strains, stresses are calculated
- Gives absolute stress value
- Measures residual strain if sample is unloaded

* depth profiling can be destructive



Strain

$$\frac{\Delta 1}{1_0}$$
 or $\frac{\Delta d}{d_0}$




Stress-Strain Relationship

$$\begin{array}{c}
1 \\
\varepsilon \text{ ii} = -- & \sigma \text{ ii} \\
E
\end{array}$$




Bragg's Law

Used to Measure Crystal Lattice Parameter, "d"






Effects of Tensile Stress on a Crystal Lattice Structure






Diffraction Pattern







Interplanar Spacings






Incident and Diffracted Beams






Stress-Strain Equation for XRD

$$\begin{split} (\epsilon_{33}) \, \phi \psi &= a_{3k} \, a_{3l} \, \epsilon_{kl} \\ a_{1k} &= \begin{vmatrix} \cos \phi & \cos \psi & \sin \phi & \cos \psi & -\sin \psi \\ -\sin \psi & \cos \phi & \sigma \\ \cos \phi & \sin \psi & \sin \phi & \sin \psi & \cos \psi \end{vmatrix} \\ (\epsilon_{33}) \, \phi \psi &= \frac{d \phi \psi - d_0}{d_0} = \epsilon_{11} \text{cos}^2 \phi \sin^2 \psi + \epsilon_{12} \text{sin}^2 \phi \sin^2 \psi \\ &\quad + \epsilon_{22} \text{sin}^2 \phi \sin^2 \psi + \epsilon_{33} \text{cos}^2 \psi \\ &\quad + \epsilon_{13} \text{cos}^2 \phi \sin^2 \psi + \epsilon_{23} \text{sin}^2 \phi \sin^2 \psi \\ &\quad = 1/2 S_2 (\sigma_{11} \text{cos}^2 \phi + \sigma_{12} \text{sin}^2 \phi \sin^2 \psi + \sigma_{22} \text{sin}^2 \phi] \, \sin^2 \psi \\ &\quad + 1/2 S_2 \sigma_{33} \text{cos}^2 \psi + S_1 [\sigma_{11} + \sigma_{22} + \sigma_{33}] \\ &\quad + 1/2 S_2 (\sigma_{13} \text{cos} \phi + \sigma_{23} \text{sin} \phi] \, \sin^2 \psi \\ &\quad \text{Assuming} \, \, \sigma_{33} = \sigma_{13} = \sigma_{23} = 0 \\ &\quad \frac{d \phi \psi - d_0}{d_0} = 1/2 S_2 [\sigma_{11} \text{cos}^2 \phi + \sigma_{12} \text{sin}^2 \phi + \sigma_{22} \text{sin}^2 \phi] \, \sin^2 \psi + S_1 [\sigma_{11} + \sigma_{22}] \\ &\quad \frac{d \phi}{d_0} \, \psi = o - d_0 \\ &\quad \frac{d \phi}{d_0} \, - \, \frac{d_0 \psi = o}{d_0} - \frac{d_0}{d_0} = \, \frac{d_0 \psi - d_0 \psi = o}{d_0} = \frac{1}{2} S_2 \, \sigma_\phi \sin^2 \psi \\ &\quad \frac{d_0 \psi - d_0}{d_0} - \, \frac{d_0 \psi = o}{d_0} - \frac{d_0}{d_0} = \, \frac{d_0 \psi - d_0 \psi = o}{d_0} = \frac{1}{2} S_2 \, \sigma_\phi \sin^2 \psi \\ &\quad 1/2 \, S_2 = \frac{1 + v}{E} &\quad S_1 = \frac{-v}{E} \end{split}$$




Single Exposure Technique





Double and Multiple Exposure Technique






Multiple Exposure (sin²ψ) Technique

$$d_{\Phi\psi} - d_{\Phi\psi} = o \qquad m$$

$$\sigma_{\Phi} = \frac{1/2S_2 \sin^2 \psi d_o}{\sin^2 \psi d_o} \qquad \frac{(1+\nu)/E d_{\Phi\Psi}}{\cos^2 \psi d_o} = o$$



Multiple Exposure (sin²ψ) Technique





X-Ray Diffraction Stress Measurement

- Can distinguish metallurgical and mechanical conditions such as:
 - large grain size
 - preferred orientation
 - stress gradients
 - surface distortion
 - shear stresses
 - plastic strain indication
 - hardness in steels





X-Ray Diffraction Stress Measurements

- Peak width analysis
 - Indication of plastic strain
 - Can be calibrated to indicate hardness in steels



Peak Width Analysis








X-Ray Diffraction Stress Measurements

- Depth profiling corrections
 - Stress Gradient corrections
 - Layer removal correction



Examples of d-spacing Versus sin²ψ Plots





Monitor and Control Quality of Many Processes

- Shot Peening
- Grinding
- Heat Treating
- Plating
- Welding
- Forging



Aerospace Applications

- Engine Components
 - Fan Blades, Compressor Blades, Turbine Blades, Disks, Diffusers, Bearings, Propeller Blades
- Rocket Monitor Cases
- Structures
 - Landing Gears, Skins, Wheels, Bulkhead, Wing Spars




The TEC 4000 X-Ray Diffraction System






Residual stress profile in strain-free baseline propeller blade sample.






Residual stress levels after cold rolling, as measured in the shank






Residual stress profiles of the group of OEM-rolled service blades






Comparison of residual stress profiles resulting from organic rerolling and OEM rolling






Correlation of principle residual stresses by x-ray diffraction and equivalent uniform stresses by Restress in the strain-free case






Correlation of principle residual stresses by x-ray diffraction and equivalent uniform stresses by Restress in the re-rolled case






Correlation of principle residual stresses by x-ray diffraction and equivalent uniform stresses by Restress in the OEM-rolled case






Results

Depth of plasticity in rerolled and OEM-rolled conditions





Correlation of Residual Stress and Diffraction Peak Width Profiles





Conclusions

- Due to severity of service conditions, beneficial compressive stresses can be induced by rolling propellers during manufacturing
- Blades can be rerolled to restore beneficial stresses that fade during service
- Stress levels at and through the surface can be determined by xray diffraction